



# SOFTWARE UPGRADE PROCEDURE

<b>MODEL NUMBER</b>	<b>M12/M32</b>
<b>REFERENCE NUMBER</b>	<b>TD2017-06-M12/M32 MDC HDM-2</b>
<b>DATE</b>	<b>12 December 2017</b>

## A MDC HDM-2 INSTALLATION

- 1 Remove applicable rear panel MDC Classic cover and top cover by loosening and taking out the screws holding them in place.

*Installation location of MDC HDM-2 (as viewed from the rear panel)*

- M12: Any of the three slots from the right side
  - M32: Any of the two slots from the right side
- 2 Remove the protective tape (if any) from the MDC HDM-2 contact terminals.
  - 3 Slide MDC HDM-2 module through the rail pushing all the way to corresponding female connectors.
  - 4 Make sure MDC HDM-2 module is locked in.
  - 5 Use corresponding screws to fix into place MDC HDM-2 module and top cover.

## B MDC HDM-2 UPGRADE PROCEDURE

### **IMPORTANT!**


*Ensure that your M12 or M32 is updated to the latest firmware. Find M12 or M32 product page from the NAD website and check for any firmware upgrade notice.*


- 1 Unzip firmware file. From the unzipped file, cut and paste the file "m12\_h.bin" (or "m32\_h.bin") to a USB memory stick.
- 2 Connect the USB memory stick (with "m12\_h.bin" or "m32\_h.bin" file already stored) to the following
  - M12: Front panel USB FRONT input
  - M32: Rear panel USB SERVICE port



# SOFTWARE UPGRADE PROCEDURE

MODEL NUMBER	M12/M32
REFERENCE NUMBER	TD2017-06-M12/M32 MDC HDM-2
DATE	12 December 2017

- 3 With M12/M32 plugged-in to a mains power source, switch ON the rear panel POWER switch.
- 4 Press  (Standby) button at the top edge of the front panel. Front panel display will illuminate.
- 5 Firmware upgrade for MDC HDM-2 will start automatically – refer to the front panel display to monitor upgrade progress.
- 6 The firmware upgrade process is completed when the display shows



*Sample shown is for M12. Display may vary. The important word to watch out is "Success" and the firmware update is completed.*

- 7 Switch off rear panel POWER switch. Unplug the USB stick from the corresponding USB port. MDC HDM-2 firmware upgrade is now completed.

## C HOW TO SHOW FIRMWARE VERSION DETAILS AND/OR RESTORE M12/M32 TO FACTORY DEFAULT SETTINGS

- 1 At any Source, press and hold "Main" in the front panel screen display until next display appears.





# SOFTWARE UPGRADE PROCEDURE

<b>MODEL NUMBER</b>	<b>M12/M32</b>
<b>REFERENCE NUMBER</b>	<b>TD2017-06-M12/M32 MDC HDM-2</b>
<b>DATE</b>	<b>12 December 2017</b>

- 2 Applicable MCU, LCD, Audio,USB or HDMI firmware version details are shown (*Sample shown is for M32. Firmware version details are examples only*). Press “Factory Reset” to initiate restoring M12/M32 to factory default settings.



- 3 Select “Yes” to Factory Reset or “No” to retain current settings.

