



Introduction

These release notes are for the NAD T187 Driver. This driver supports serial and IP control. It can be used to control the following products:

- NAD T187.

Dependencies

- Requires Control4 OS 2.10.2 or higher.

Change Log

Version 2 (released May 9, 2019):

- Code optimization.

Version 2 (released December 19, 2018):

- Improved support for Audyssey listening modes.

Version 1 (released August 29, 2018):

- Initial public release.
- Supports the following functions:
 - Power off, power on, power query
 - Mute, unmute, mute query
 - Volume up, volume down, volume set, volume query
 - Navigation control (Up, Down, Left, Right, Enter)
 - Source selection
 - Listening mode change

Notes

- Serial control is 115200 baud / 8 data bits / 1 stop bits / no parity / no flow control.