



# CHASSIS DRIVER INTEGRATION BULLETIN

---

<b>Product</b>	CI 8-120, CI 8-150, CI 16-60	<b>Reference No.</b>	CDIB-CIAMP2022-04
<b>Subject</b>	CI 8-120, CI 8-150, CI 16-60 RT1 Chassis Driver	<b>Date</b>	31 March 2022

---

---

<b>DESCRIPTION</b>	Describe current functionality and use of the generic NAD CI-Amp chassis driver for use with <b>RT1</b> custom control systems
--------------------	--

---

## INTRODUCTION

This document describes the current functionality and use of the generic NAD CI-AMP chassis driver for use with RTI Control system.

## FIRMWARE REQUIREMENTS

Ensure that your NAD CI amplifier has been updated to the following minimum firmware versions

- CI8-120 Mainmcu Version v2.26
- CI8-150 Mainmcu Version v2.15
- CI16-60 Mainmcu Version v2.05
- RTI Integration Designer updated to a minimum of v9.20, and/or Integration APEX updated to a minimum of v10.13

## SUPPORTED FEATURES

The driver provides few basic commands:

- Mute On/Off/Toggle
- Global Control On/Off
- Power On/Off/Toggle
- Source Switch
- Set Output Preset

## NOTE

*The AMP does not provide volume control. Volume needs to be controlled by upstream device.*